



Heated Back and Seat Massager
Model: 226



Instruction Manual

Assembly Instructions

NOTES:

- Do not setup the massager in a bathroom or similarly humid areas as such an environment may reduce the lifespan of the massager mechanism.
- Ensure the massager is not exposed to direct sunlight, placed near heaters or other heat sources.
- **DO NOT** use this product on any wooden surface as the zipper may cause damage.

Strapping System

This back massager incorporates a unique strapping system, which allows you to fasten it to almost any chair or auto seat. Set the cushion in your seat and adhere the elastic straps firmly around the seat back. Your massager won't slip or slide around.

For Use in Home or Office

Plug adaptor into a 230 volt AC outlet and plug the receptacle end into the input jack, located along the side of the cushion. Attach the massage cushion to any chair for a luxurious massage as you read, rest or even work.

For Use in the Car

Simply plug the 12-volt auto adaptor into a cigarette outlet and plug the receptacle end into the input jack, located along the side of the cushion. Slip the massage cushion straps over your seat to enjoy a relaxing massage as you drive.

Product Specification:

Input: 12VDC 800MA

Power: 14W (When using AC adapter).

How to use your Heated Back and Seat Massager Remote Control

Heat button: Turns lumbar heater on/off.


Power button: Turns massager on/off.

Intensity button: Adjusts the strength of your massage. Choose from 4 levels of intensity.

Mode button: Cycles through the 4 different massaging modes: Pulsate, Tapping, Rolling, Kneading and Auto mode. Auto mode will automatically change through the various massaging modes.

Isolating your Message: Customise your massage areas by choosing to turn on/off the various parts of the massager: Upper back, Lower back, Hips and Thighs.

Timer button: Choose between 15min, 30min and 60min settings.



Although the automatic timer will allow pre-set treatments for 15, 30 or 60 minutes it is recommended to limit the use to 15 minutes when the heat feature is on. Extensive use could lead to the excessive heating of the product and may shorten its working life. Should this occur, discontinue use and allow the unit to cool before operating again.

Important Safety Instructions

Please keep this instruction manual in a safe place, along with the purchase receipt and carton for future reference. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

- If the supply cord is damaged, the manufacturer or its service agent or a similarly qualified person must replace it in order to avoid a hazard.
- Before turning on, ensure the electrical voltage and frequency of the circuit correspond to those indicated on the adaptor.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not operate the appliance outdoors.
- The adaptor must be removed from power socket before cleaning, servicing, maintenance or moving the appliance.
- When the appliance is not in use, switch it off and unplug it.
- To reduce the risk of electrocution, never operate this product with wet hands, submerge under water or spill liquids into the product.
- Do not insert any objects into the massager.
- Do not kink or damage the power cord.
- Improper installation may result in the risk of fire, electric shock and or injury to persons.
- The manufacturer is not responsible for any eventual damages caused by improper or faulty use.
- The unit has no user-serviceable parts contained within. Do not attempt to repair, disassemble or modify the appliance.
- Do not use chemical, steel wool or abrasive cleaners to clean the outside of the massager as these chemicals may damage the material.
- The massager is intended for household use only. Do not use this appliance for anything other than its intended use.
- Do not operate the unit near liquids (kitchen sink, water basins, taps etc).
- Do not use this appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.

Important Safety Instructions

- Never leave the appliance unattended while in use.
- Do not use your massager if it or its cord or controller has been damaged or if it is not working properly. Return your massager to an Appointed Service Center for examination and/or repair.
- If you have any concerns regarding your health, consult your doctor before using the product.
- Individuals with pacemakers should consult a doctor before use.
- Never cover the appliance when it is in operation.
- Extensive use could lead to the product excessively heating and shorten product life span. Should this occur, discontinue use and allow the unit to cool before recommencing operation.
- Never use this product on swollen or inflamed areas or skin eruptions.
- This product is a non-professional appliance designed to provide soothing massage to muscles.
- DO NOT use this product as a substitute for medical attention.
- DO NOT use this product before bed. The massage has a stimulating effect and can delay sleep.
- DO NOT use this product while in bed.
- This product should NEVER be used by any individual suffering from any physical ailment that would limit the user's capacity to operate the controls or who has sensory deficiencies in the lower half of their body.
- Do not use if wet.
- Do not use with a disabled person, infant or a person insensitive to heat without medical consultation first.
- Do not use when folded.

Notes:

Notes:

Care & Cleaning instructions

- Unplug the unit and allow it to cool before cleaning. Clean only with a soft, slightly damp sponge. Never allow water or any other liquids to come into contact with the unit
- DO NOT immerse in any liquid to clean.
- Never use abrasive cleaners, brushes, gasoline, kerosene, glass/ furniture polish or paint thinner to clean.



Lifemax Ltd
1 Pipers Court,
Thatcham, Berkshire,
RG19 4ER, England
www.lifemaxuk.co.uk

Please retain this information for future reference.